



*"Setting the World's  
Performance Standards!"*


743 E. Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

## **SLP Engine Push Arm for 2006-07 Polaris 600 H.O. RMK P.N. 23-62**

### **Kit Contents:**

- 1 - Push Arm Assembly
- 2 - Self Tapping Bolts
- 1 - Instruction Sheet

1. Remove exhaust pipe.
2. On the right hand front corner of the bulkhead (mag side), set the push arm into place centering it over the rivet in the bulkhead (see illustration). Set the torque stop snug against the recoil housing (make sure bracket is tight against the bulk head) and lock in place with the jam nut. Using the holes in the top of the bracket as a guide mark and drill the holes with a #7 drill bit. Bolt into place using self tapping bolts provided.
3. Re-install exhaust pipe.



**Front of  
the sled**

