



*"Setting the World's
Performance Standards!"*

743 E. Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

SLP Hot Air Outlet Vent Kit For 2012-17 Arctic Cat F, XF, M & ZR 8000, 2014-17 Yamaha Viper Part #32-606

Kit Contents:

- 2 - Vents (#32-6061)
- 8 - Plastic Rivets (#14-223)

1. Remove seat and lower rear cowling.

NOTE: If cowling is not removed gas tank damage can occur.

2. Place vent onto the cowling and mark around the outside edge.

3. Cut out the outside edge of the supplied template. Align template on the lower bottom of the cowling (see illustration) and tape into place. Using a center punch mark the center of all the holes. Remove template and repeat on the other side.

4. Using a 1" hole saw carefully drill all 24 holes and debur.

5. Using the vent as a guide drill the 4 mounting holes with a 3/16" (#11) drill bit. Rivet into place using the supplied plastic rivets.

6. Reinstall cowling and seat.



