

743 E. Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

## **Anti-Stab Wheel Kit**

Anti-Stab Wheel Kits are available in two styles. The centered wheel kit is for suspensions with offset or dual limiter straps and the other is for suspensions with centered limiter straps.

If using <u>without</u> anti-ratchet drivers, remove the stock front cross shaft and install Anti-Stab Wheel kit in its place.

If using with anti-ratchet drivers or in other situations that require shortening your suspension rail or removing rail tip protectors it is necessary to install an Anti-Stab Wheel Kit. Installation is simple, by drilling a 3/8" hole in each suspension rail 1/2" back from end of rail and 1 1/4" up from bottom of Hyfax. It is recommended to use thread lock when installing bolts. Periodically check bolt tightness after installation. Recommending cycling suspension to check for driver clearance after installation of Anti-Stab wheel kit.



